


Tilling Timber Pty Ltd - Head Office 31 - 45 Orchard Street KILSYTH 3137
Tel: 03 9725 0222 Fax: 03 9725 6569 Web: www.tilling.com.au e-mail: techsupport@tilling.com.au

SmartJoist Installation Guide

General

Jobsite handling and storage, erection procedure and erection bracing are the responsibility of the installer. Careful review of this installation guide, project plans and joist layout drawings (where supplied) should be undertaken prior to the installation of the joists. The manufacturer's warranty applies only to properly installed undamaged joists, adequately protected from the weather in the completed project.

SmartJoist sizes




SAFETY WARNING !

DO NOT ALLOW WORKERS OR LOADS ON SmartJoists UNTIL ALL BLOCKING, HANGERS, RIM JOISTS, NAILING AND TEMPORARY BRACING ARE INSTALLED AS SPECIFIED.

SERIOUS ACCIDENTS OR INJURY CAN RESULT FROM FAILURE TO FOLLOW THESE GUIDELINES.

SAFETY WARNING



DO NOT ALLOW WORKERS OR LOADS ON SmartJoists UNTIL ALL BLOCKING, HANGERS, RIM JOISTS, NAILING AND TEMPORARY BRACING ARE INSTALLED AS SPECIFIED BELOW. SERIOUS ACCIDENTS OR INJURY CAN RESULT FROM FAILURE TO FOLLOW THESE GUIDELINES.






ACCIDENTS CAN BE AVOIDED UNDER NORMAL CONDITIONS BY FOLLOWING THESE GUIDELINES:

1. Brace each joist as it is erected. Joists must be nailed to supports and all hangers, blocking, rim joists. X - bridging at supports must be completely installed and properly nailed. (see general notes - page 5)
2. Brace the ends of cantilevers (overhangs) with closure panels, rim joist or x - bridging (see general notes - page 5)
3. Lateral brace the top flange of each joist, to prevent sideways buckling or rollover which may occur under light construction loads, such as a worker and/or a layer of un-nailed sheathing. Fully installed permanent sheathing or temporary struts to the top flange of each joist (see 'typical SmartJoist floor framing - page 6) can accomplish lateral bracing.
4. Temporary struts must be nailed to a lateral restraint at the end of bay such as a braced wall or temporary (or permanent) sheathing nailed to the first 1200 mm of the joist at the end of the bay (see typical floor framing - page 6)
5. Permanent sheathing must be completely installed and properly nailed before additional loads can be placed on the system.
6. The integrity and safe use of these products can be seriously impaired if they are damaged. Do not install any damaged products. Contact your Tilling representative or the Technical Support Customer HelpLine on 1300 668 690 if any product damage is noted.

Handling and storage of SmartJoists

SmartJoists should be stacked in the upright position to avoid any damage during handling or storage.




Bearers at a maximum of 4.0 metre centres

Use bearers to keep stacked material away from damp surfaces. align bearers vertically

Safe loading of materials on a working platform

IMPORTANT - Joists must be fully braced or have floor sheeting installed before applying any of the following loads.

- 200 kg per joist for joists less than 240 mm deep
- 250 kg per joist for joists 240 mm and greater




Notes:

1. Deflection limit is taken as span/200
2. All timber must be kept dry when applying maximum temporary loading
3. Loads are to be spread equally over a minimum of 2 joists, using timber bearers at a minimum of 1200 mm in length or a standard 1200 x 1200 pallet
4. NO loads are to be stacked over any part of the lengths of the joists fixed to an opening header or trimmer joist such as a stair trimmer
5. If no plasterboard is in place under the joists, the bottom flange requires temporary bracing
6. Joists on hangers may require propping
7. If unsure about stacking concentrated loads on SmartJoist working platforms, please contact the SmartFrame Design Centre on 1300 668 690.

Durability and exposure to moisture - Untreated SmartFrame EWP

SmartLVL and SmartJoists are manufactured from softwoods and hardwoods having a durability rating of class 4, which is the same rating as some Ash type Eucalypts. Untreated SmartJoists and SmartLVL should not be used where the equilibrium moisture content is likely to remain above 20% for an extended period.

Untreated SmartLVL is suitable in the *internal, fully protected, ventilated* and the *external above ground, protected* zones of the structure as shown on the next page. Untreated SmartLVL is not suitable for *external above ground, exposed* or humid indoor conditions, such as swimming pool enclosures.




Definitions of exposure zones within a structure

* External timbers are regarded as protected in AS 1684 if they are covered by a roof projection (or similar) at 30° to the vertical and they are well detailed and maintained (painted and kept well ventilated).


H3 Deck bearers and joists

H3 Treated Deck joists and bearers are a common application for treated SmartLVL 15. The diagram demonstrates the minimum construction detailing for H3 treated joists and bearers. Failure to follow these guidelines may render treatment warranties void.



Recommended proprietary top protection for joists and bearers

It is a requirement that any cuts, notches or penetrations made in LOSP treated LVL be painted with a suitable "brush/spray on" preservative such as "Enseal". (Enseal is available as part of any SmartFrame H3 LOSP order)




Recommended Fastening to SmartLVL Deck Joists.

* Painting as per "Painting of SmartGuard LOSP Treated SmartLVL 15" in the SmartLVL 15 Design Guide

SmartJoists - General notes

Do NOT start toe nail into the corner of the flange or the top of the flange.

MAXIMUM Nail diameter 3.15 mm



1. Except where otherwise noted, 30 mm minimum bearing is required at joist ends and 42 mm minimum bearing is required at intermediate supports.
2. Nail joists at each bearing with 2 of 3.15 Φ x 65 nails, using one each side placed 30 mm from the end to avoid splitting.
3. SmartJoist blocking or Rimboard - face nail to bearing plate with 3.15 Φ x 65 nails at 150 mm centres. Nail rim joist to the end of the top and bottom flange of each SmartJoist with 1 3.15 Φ x 65 nail, use 1 3.75 Φ x 75 nail top and bottom with joists with 58 or 90 mm wide flanges.
4. SmartRim - toe nail to bearing plate with 3.15 Φ x 65 nails at 150 centres or 4.5 Φ x 75 nails at 300 centres. Nail rim to the end of the top and bottom flanges of each SmartJoist with 1 3.15 Φ x 65 nails.
5. Sheathing nailing to top flange (Joists must be fully braced before sheathing is nailed)
 - Space 2.8 Φ x 65 and 3.15 Φ x 65 nails no closer than 50 mm per row.
 - Space 3.75 x 75 nails no closer than 75 mm.
 Maximum nail spacing: 300 mm
6. Backer blocks at hanger details:
 - 40 mm flanges - 15 mm ply
 - 44 & 51 mm flange - 19 mm ply
 - 58 mm flange - 2 pieces of 12 mm ply
 - 70 mm flange - 2 pieces of 15 mm ply
 - 90 mm flange - 2 pieces of 19 mm ply
7. See double SmartJoist detail F15 for filler blocks. Nail Joists together with two rows of 3.75 Φ x 75 nails on each side of double joist at 300 mm centres (Clinch if possible). A total of 4 nails per 300 mm is required. If nails can be clinched, only 2 nails per 300 mm is required.
8. All joists require lateral support at end bearings using blocking or rim material.
9. The top flanges must be kept straight within 10 mm of the true alignment.
10. See web stiffener detail F13 for web stiffener attachment at supports. Web stiffener requirements for concentrated loads in excess of 4.5 kN, applied at the top flange of the joist, requires additional consideration.
11. When required, install web stiffeners to joist (see detail F13) prior to placing joist in the hanger, then nail hanger to joist.
12. All roof details are valid to a maximum angle of 35° (as per AS1684 - 1999)
13. All nails are steel nails complying with AS 2334 - 1980 Steel nails - Metric series. Nail gun nails of similar length and diameter may be substituted for the above provided that they are manufactured with properties equivalent to the nails in the above code.
14. Install all hangers to the manufacturers installation instructions, taking particular attention to the use of the correct nails. Never use clouts or brads.
15. Prescriptive code requirements for mid span blocking of solid timber joists are not applicable to SmartJoists.

End blocking and SmartJoist

The end blocking of I-Joists performs three (3) essential functions, as well as being an invaluable component of the bracing of the structure as a whole unit. These functions include:


- (1) Keeps joists upright and prevents rollover during construction
- (2) Provides end reaction capacity to the I-Joists and

- (3) Provides extra torsional resistance to the I-Joist to improve floor performance.


(A full description of the end blocking effects is contained in the SmartJoist Design Guide).

The SmartJoist floor joists should be fully blocked at their end bearing points onto exterior load bearing walls as shown in the blocking options following.

Typical SmartJoist Floor Framing



Typical SmartJoist Floor construction details





Concentrated Roof loads

Note:
To achieve the necessary racking resistance through the floor diaphragm, it is important that the nailing provisions of the floor sheeting to the joists as described in AS 1684 (AS 1869 for particle board) be adopted to nail the floor sheeting to the Rim Joist or SmartRim in details F1-F3

Typical SmartJoist floor construction details (cont'd)

WARNING - Correct blocking for SmartJoists

F6




Green timber shall not be used under any circumstance


All blocking shall be carried out as per details F1-F3, with blocking to extend to both flanges and skew nailed with 3.15 Φ x 65 nails, one each side of top and bottom flange.

Interior loading bearing and bracing walls

F7




F8



NOTE: Detail F7 with blocking panel is required for bracing walls.

Non load bearing cantilevers (balconies)

F9




Non Load bearing wall to a maximum height of 2400 mm

Min F7 - Durable or treated timber (Uniform loads ONLY).

Backer block - nail with 2 rows of 3.75 dia x 65 mm nails at 150 centres and clinch

F9



For cantilevered joists supporting load bearing walls see details C1-C4 on page 23

Joist hanger details

Nailing

Use only the listed galvanised bracket nails. All holes are to be filled with the specified nails in order to achieve the stated hanger capacity. Alternatively, screw with 35 x 6 gauge bugle-head or wafer-head wood screws. The joist hangers below have been developed specifically for SmartJoists. The joist hangers and nails are available from Tilling Timber as part of a SmartFrame order. It is not recommended that joist hangers other than those listed below be used with SmartJoists.

SmartJoists brackets in areas shaded require web stiffeners as per detail F13

SmartJoist	face mount code	hanger capacity Φ kN *	face nail holes	nail size	top mount code	hanger capacity Φ kN *	face nail holes to support	top nail holes	nails to joist	nail size
Single joist face mounts					Single joist top mount					
SJ20044	20044F	6.2	8	3.75 x 40	20044T	4.8	2	4	2	3.75 x 40
SJ24040	24040F	7.8	10	3.75 x 40	24040T	4.8	2	4	2	3.75 x 40
SJ24051	24051F	7.8	10	3.75 x 40	24051T	4.8	2	4	2	3.75 x 40
SJ24070	24070F	7.8	10	3.75 x 40	24070T	4.8	2	4	2	3.75 x 40
SJ24090	24090F	7.8	10	3.75 x 40	24090T	4.8	2	4	2	3.75 x 40
SJ30040	30040F	9.3	12	3.75 x 40	30040T	4.8	2	4	2	3.75 x 40
SJ30051	30051F	9.3	12	3.75 x 40	30051T	4.8	2	4	2	3.75 x 40
SJ30070	30070F	9.3	12	3.75 x 40	30070T	4.8	2	4	2	3.75 x 40
SJ30090	30090F	9.3	12	3.75 x 40	30090T	4.8	2	4	2	3.75 x 40
SJ36058	36058F	10.9	14	3.75 x 40	36058T	4.8	2	4	2	3.75 x 40
SJ36090	36090F	10.9	14	3.75 x 40	36090T	4.8	2	4	2	3.75 x 40
SJ40090	40090F	10.9	14	3.75 x 40	40090T	4.8	2	4	2	3.75 x 40

Double joist face mounts					Double joist top mounts					
2/SJ20044	20044DF	6.2	8	3.75 x 40	N/A					
2/SJ24040	N/A				24040DT					
2/SJ24051	24051DF	7.8	10	3.75 x 40	24051DT	4.8	2	2	4	3.75 x 40
2/SJ24070	24070DF	7.8	10	3.75 x 40	24070DT	4.8	2	2	4	3.75 x 40
2/SJ24090	24090DF	7.8	10	3.75x40	24090DT	5.7	2	4	2	3.75 x 40
2/SJ30040	N/A				N/A					
2/SJ30051	30051DF	8.7	12	3.75 x 40	30051DT	4.8	2	2	4	3.75 x 40
2/SJ30070	30070DF	8.7	12	3.75 x 40	30070DT	4.8	2	2	4	3.75 x 40
2/SJ30090	30090DF	8.7	12	3.75 x 40	30090DT	5.7	2	4	2	3.75 x 40
2/SJ36058	N/A				36058DT	4.8	2	4	2	3.75 x 40
2/SJ36090	N/A				36090DT	5.7	2	4	2	3.75 x 40

Skewed left or right (face mount)

SmartJoist	SmartFrame code	hanger capacity Φ kN *	face nail holes	Nails to joist	nail size
SJ20044	20044FR or FL	6.2	8	2	3.75 x 40
SJ24040	N/A				
SJ24051 - SJ30051	240-30051FR or FL	6.2	8	2	3.75 x 40
SJ24070	N/A				
SJ24090	24090FR or FL	6.2	8	2	3.75 x 40
SJ30040	N/A				
SJ30051	30051FR or FL	7.8	10	2	3.75 x 40
SJ30090	30090FR or FL	7.8	10	2	3.75 x 40
SJ36058	36058RR or FL	7.8	10	2	3.75 x 40
SJ36090	36090FR or FL	7.8	10	2	3.75 x 40
ALL	LVSIA	5.5	4	1	12 g x 35 screw

Variable Slope (face mount - usually for rafters)

SmartJoist	SmartFrame code	hanger capacity Φ kN *	face nail holes	Nails to joist	nail size
SJ20044	20044VS	4.6	10	7	3.75 x 40
SJ24051 - SJ30051	240-30051VS	4.6	10	7	3.75 x 40
SJ24070 - SJ30070	N/A				
SJ24090 - SJ40090	240-40090VS	9.9	18	12	3.75 x 40
SJ36058	36058VS	4.6	10	7	3.75 x 40


NOTES:

* Hanger capacity is based upon dead load + floor live load for a supporting beam of joint strength JD5.


$k_1 = 0.69$, Capacity factor $\phi = 0.85$. For permanent loads, the above value should be multiplied by $0.57/0.69 = 0.82$.

General connector installation details


Positive angle nailing



Correct nailing




Nail at wrong angle




Nail too long

Top mount hangers




Hanger over spread
If hanger is overspread, I-Joist may be raised above header, also, NO support for top flange.




Hanger not plumb
A hanger kicked out from the header can cause uneven surfaces.

Prevent rotation


Hangers provide some joist rotation resistance; however, additional lateral restraint may be required for deep joists.



No web resistance
Results in rotation



No web stiffener required
Hanger side flange supports joist top flange.



Web stiffener required
Hanger side flange should be at least 60% of joist depth or potential joist rotation must be addressed.



Correct fasteners



Bracket capacities are based upon using the correct bracket nail as per the table within the SmartJoist Design Guide. Bracket nails have special heads to provide strength. Clouts, brads etc. are NOT suitable as bracket nails

SmartJoist headers

Backer blocking each side, hanger nails must extend past the supporting joist's web member into the backer blocking.





Face mount connection to web

Bottom flange pulling off when Backer block on one side only.

The top flange of the supporting joist must be supported by backer blocks to prevent crossgrain bending and rotation.

Top mount connection




Cantilevered balconies as per detail F9

Loadings: Permanent Loading G: self weight + 40 kg/m² + 0.6 kPa of live load permanently applied,
live load Q: 2.0 kPa or 1.8 kN point live load , 1.5 kN/m acting at end of cantilever
Balcony Cantilevers - Maximum cantilever and minimum back span (m)

Joist spacing (mm)	300		400		450		600	
Cantilever material	Cantilever	Back span						
H3 SmartFrame LVL 15								
150 x 42	1.0	1.5	1.0	1.5	1.0	1.5	0.9	1.4
170 x 42	1.2	1.8	1.1	1.7	1.1	1.7	1.1	1.7
200 x 42	1.4	2.1	1.3	2.0	1.3	2.0	1.3	2.0
240 x 42	1.7	2.6	1.6	2.4	1.6	2.4	1.5	2.3
300 x 42	2.1	3.2	2.0	3.0	2.0	3.0	1.9	2.9
H3 MGP 10								
140 x 45	0.7	1.1	0.7	1.1	0.7	1.1	0.7	1.1
190 x 45	1.1	1.7	1.1	1.7	1.1	1.7	1.1	1.7
240 x 45	1.5	2.3	1.4	2.1	1.4	2.1	1.4	2.1

Backer and filler blocks




Filler blocks and web stiffeners

SmartJoist code	Recommended filler block	Web stiffener material	
		stiffener	nails
SJ20044	120x35	15x60 mm ply	4-3.15x65
SJ24040	140x35	15x60 mm ply	4-3.15x65
SJ24051	140x45	19x60 mm ply	4-3.15x65
SJ24070	150x58 LVL	2/15x60 mm ply	4-3.15x65
SJ24090	2/140x45	2/19x60 mm ply	5-3.15x65
SJ30040	190x35	15x60 mm ply	4-3.15x65
SL30051	190x45	19x60 mm ply	4-3.15x65
SJ30070	150x58 LVL	2/15x60 mm ply	4-3.15x65
SJ30090	2/190x45	2/19x60 mm ply	5-3.15x65
SJ36058	250x50	2/12x60 mm ply	5-3.15x65
SJ36090	2/240x45	2/19x60 mm ply	5-3.15x65
SJ40090	2/240x45	2/ ply	5-3.15x65


NOTES:

1. Use plywood sheathing for web stiffener with face grain parallel to long axis of the stiffener
2. Filler blocks noted are for the general requirements of the details within this design guide
3. Leave 3 mm gap between top of filler blocks and bottom of top flange
4. Support back of web during nailing to prevent damage to web/flange connection
5. Filler block is required full length of joist.



Concentrated loads on SmartJoists

Web stiffeners under concentrated loads are required as shown below for concentrated loads that exceed 6.5 kN ONLY.




NOTE:

1. Web stiffeners are NOT required at end bearing supports when span length are taken from the SmartJoist Design Guide, except where they are required to prevent rotation if the joist hanger does not laterally restrain the top flange
2. Web stiffeners may be required at inner supports under concentrated loads. Consult the appropriate tables.

Multiple SmartJoist members

(a) filler blocks



(b) SmartJoist MultiJoist Clips MJC



The SmartFrame I-Clip is Australia's first backer and filler free solution to join multiple SmartJoist members

2 ply SmartJoist supporting concentrated loads


SmartJoist Applications - Characteristic Concentrated loads (kN)	
No of MJC's	Max incoming Concentrated Load
4	16.4
8	24.6

2 ply SmartJoist supporting regular loads

SmartJoist Applications - Characteristic Regular loads (kN)	
No of MJC's	Max incoming regular Load
2	8.2
4	12.3



Fastener spacing



Minimum single row fastener spacing into SmartJoist flanges						
Fastener type and size	SmartJoist flange width					
	40 mm flange	44 mm flange	51 mm flange	58-70 mm flange	90 mm flange	
Nails	2.8 x 60	75	75	50	50	50
	3.15 x 60	100	90	75	75	75
Screws	9g x 45	150	150	75	75	75
	10g x 50	150	150	100	75	75

NOTES:


1. Nailing of bottom plate at 100 mm centres through floor sheathing and into top flange is permitted
2. Minimum nail/screw spacing is shown above, maximum nail/screw spacing is set by the flooring manufacturer, in absence of manufacturers data, 300 mm centres
3. Tighter effective nail spacing may be obtained by offsetting nail/screw rows a minimum of 12 mm and maintaining a 10 mm minimum edge distance.
4. Do not use nails/screws of a larger diameter than those shown above when attaching sheathing to SmartJoists

Limited end notching at supports

The cutting of notches in the ends of joists may reduce the allowable end reactions.

The amended end reaction capacities of SmartJoists with a 12 mm notch are as follows:


- Without web stiffeners - 80% of end reactions.
- With added web stiffeners (as per detail F13) - Full end reaction capacity





DO NOT OVER CUT FLANGES. SUBSTANTIAL REDUCTIONS IN CAPACITY MAY OCCUR IF FLANGES ARE OVER CUT

To maintain the end reaction capacities above, end flange notching is strictly limited to:

1. Notch depths NOT greater than 12 mm
2. Notches cleanly cut - NO over cutting
3. Notch length not to exceed more than 5 mm past the support.





Example fixing of SmartJoists to steel beams




Example fixing of SmartJoists to steel beams (Cont'd)


LOWER FLANGE BEARING



FACE MOUNT HANGER




EXAMPLE FIXING OF SmartJoists TO BRICK OR MASONRY WALLS





Tie down (bracing wall) details

The tie-down needs of the structure are related to the applied wind loads. Reference should be made to AS 1684 for further guidance on this issue. The general details relating to the tie-down provisions of solid end section timber may be adopted for SmartJoists, except that under NO circumstances is it permitted to bolt through either the top or bottom flange, except when the joist is fully supported upon a wall plate or similar as shown below.





DO NOT DRILL THROUGH EITHER FLANGE OF SmartJoists unless they are fully supported on wall plate or similar




Extra details where bracing walls are parallel to the joists can be found in the SmartJoist Design Guide, the SmartFrame software or at www.tilling.com.au

Cyclone rod tie down for cantilevered SmartJoist floors



Cyclone strap capacities


Where the strap ends of the cyclone strap are wrapped around the wall plate or other timber member and are fixed with 4 of 3.15 \varnothing x 35 nails, the design capacity $\varnothing N_d$ of 15.3 kN is applicable, regardless of the timber joint group. Tests have proven that bending the legs of cyclone straps around the timber increases the ultimate load capacity.



While double joists shown in the above diagram, it is only necessary when loads exceed the capacities of single joist cantilevers.

Joist/beam connections supporting offset load bearing walls

Modern building designs frequently call for the upper storey of a two storey dwelling to be set back from the lower wall to allow sufficient light access to all areas of the building. Provided that the SmartJoists have been designed to support this offset load, no special provisions need to be made for their support EXCEPT in the following support conditions:



Maximum Roof Area Supported (m^2)


- based upon worst case of 40 mm flange width (conservative for wider flanged joists)

Joist spacing (mm)	Joist supported on joist hanger RA1								Lower flange bearing RA2							
	300	400	450	600	300	400	450	600	300	400	450	600	300	400	450	600
Joist span (mm)	Sheet				Tile				Sheet				Tile			
3500	21.7	15.0	12.8	8.2	9.6	6.7	5.7	3.6	6.9	6.4	6.2	5.3	3.1	2.9	2.8	2.4
4000	21.1	14.5	12.3	6.9	9.4	6.4	5.5	3.1	6.7	6.2	6.0	4.6	3.0	2.8	2.7	2.0
4500	20.5	13.9	11.7	5.7	9.1	6.2	5.2	2.5	6.6	6.0	5.7	3.9	2.9	2.7	2.5	1.7
5000	20.0	13.4	10.4	4.4	8.9	5.9	4.6	2.0	6.4	5.8	5.1	3.1	2.9	2.6	2.3	1.4
5500	19.4	12.1	9.1	3.2	8.6	5.4	4.1	1.4	6.3	5.3	4.6	2.4	2.8	2.4	2.0	1.1

Support for concentrated loads - joist/beam connections supporting off-set load bearing walls

Concentrated loads from any source such as girder trusses MUST be transferred through the floor space WITHOUT adding extra vertical loads to the ends of the SmartJoist at its bearing support.

One example of transferring these loads is the use of inclined timber struts as shown below. Struts must be a tight fit and at a minimum angle of 60° to the horizontal



Beams supporting SmartJoists – multiple member laminations

Vertical laminations may be achieved by adopting the procedures described in clause 2.3 of AS1684, however these procedures should be considered as the minimum requirements to achieve the desired effect.


Experience with SmartLVL beams indicates that this degree of fixing may not satisfactorily prevent cupping of individual components as a result of the ingress of moisture between laminates during construction. The suggested method of vertical lamination below provides a greater level of fixity between individual components, and with the use of an elastomeric adhesive, also prevents moisture penetration between the laminates.

Multiple member laminating of top load- ed beams (symmetrical loading)

The edges of the individual sections must be carefully aligned to each other so that the composite beam is flat, allowing the applied loads to be equally shared.

- Depths up to and including 300 mm: 2 rows of nails as shown above at 300 mm centre
- Depths in excess of 300 mm: 3 rows of nails as shown above at 300 mm centres.

Beams supporting SmartJoists – multiple member laminations (cont'd)




Multiple member laminating of top loaded beams (Non-symmetrical loading)

Combination 1
2 pieces of
35 or 42 mm

Combination 2
3 pieces of
35 or 42 mm

Combination 3
1 piece of 35 or 42 mm
1 piece of 58 or 75 mm




Combination (see details above)	3.75Φ x 90 mm nails		12 mm Φ bolts	
	2 rows at 300 ctrs	3 rows at 300 ctrs	2 rows at 600 ctrs	2 rows at 300 ctrs
Combination 1	3400	5100	7500	15000
Combination 2	2900	4000	5600	11000
Combination 3	2900	4000	4500	11000

Notes:

1. Table values are for 40 kg/m² floors.
2. The table values for nails may be doubled for nails at 150 mm centres, and tripled for nails at 100 mm centres
3. The nail schedules shown apply to both sides of a three (3) piece beam
4. Bolts are to be grade 4.6 commercial bolts conforming to AS 1111. Bolt holes are to be a maximum of 13 mm diameter and are to be located NOT less than 50 mm from either edge.
5. All bolts shall be fitted with a washer at each end, of a size NOT less than that given in AS 1720.1 table 4.11.

Maximum floor load width supported by either outside member (mm)



How to use the maximum uniform side load table

Example: see diagram above

Beam of 2 SmartLVL loaded on both side (Combination 1)

FLW 1 = 2800 mm, FLW 2 = 2300 mm

Total FLW = 2800 + 2300 = 5100 mm.

1. Use SmartFrame software or SmartLVL safe load tables to size the two member section to support the FLW of 5100 mm.
2. Choose the larger of the side FLW's carried by the beam, in this case 2800 mm.
3. Enter the table at the "Combination 1" row and scan across to a table value greater than 2800 mm. The first value in the row at 3600 mm is greater than the 2800 mm required.
4. Thus adopt 2 rows of 3.75Φ x 90 mm nails at 300 mm centres

SmartJoist/SmartRim[®] characteristic blocking capacities

SmartRim[®]

SmartRim rimboard is an alternative solution to blocking with SmartJoists (either long length of cut to length) to support vertical and lateral wall loads as part of a floor or roof framing system.

SmartRim is a 19 mm LVL (2 veneers are cross laminated for stability) and is sold in 3.6 m lengths, precision ripped to match the height of the SmartJoist range up to and including 360 mm. (400

mm SmartRim in QLD only). Fixing of rimboard is described in detail in SmartJoist—GENERAL NOTES item 3 on page 5 of the SmartJoist Design Guide.

SmartRim has a joint strength group of JD4 on the wide face for nails, screws and bolts..

SmartJoist/SmartRim characteristic capacity values (see notes below)

Vertical load capacity (kN/m) ^{(1) (2)}	Horizontal load transfer capacity (kN/m) ^{(3) (4)}
63	6.9

Notes:

1. Vertical load capacity above is for instantaneous load conditions and must be multiplied by the appropriate k_1 factor for load condition under consideration
2. Vertical load capacity above already includes the k_{12} factor for up to 400 mm depth as per clause I2.3 of AS 1720.1
3. Horizontal load capacity above is an instantaneous load condition, with the k_1 for lateral bracing loads usually 1.0
4. The above horizontal load capacity is limited by the fixing of the SmartJoist /SmartRim to the frame and can ONLY be achieved if the fixing detail on page 7 of the SmartJoist Design Guide is strictly adhered to

Penetrations within SmartJoist and SmartRim

The maximum allowable hole size for a SmartJoist/SmartRim shall be $\frac{2}{3}$ of the rim board depth as shown below.

The length of the SmartJoist/SmartRim segment containing a hole shall be at least 8 times the hole size.

SmartJoist hole sizes and minimum length

SmartJoist/SmartRim Depth (mm)	Maximum allowable hole size ^{(a) (b)} (mm)	Minimum length of SmartJoist/SmartRim board segment ^(c) for the maximum allowable hole size (mm)
200	130	1050
240	160	1280
300	200	1600
360	235	1900
400 ^(d)	265	2100

- (a) These hole provisions do not apply to SmartJoist/SmartRim installed over openings such as doors or windows
- (b) The diameter of the round hole or the longer dimension of the rectangular hole
- (c) The lengths of the SmartJoist/SmartRim segment per wall line. For multiple holes, the minimum length of SmartJoist/SmartRim segment shall be 8 times the sum of all hole sizes.

Application Notes


1. Do not cut holes in SmartRim installed over openings, such as doors or windows, where the SmartRim is not fully supported, except that holes of 40 mm or less in size are permitted provided they are positioned at the middle depth and in the middle $\frac{1}{3}$ of the span (see note 5 for minimum hole spacing).

2. Field-cut holes should be vertically centred in SmartRim and at least one hole diameter or 150 mm whichever is less, clear distance away from the end of the wall line. Holes should never be placed such that they interfere with the attachment of the rim board to the ends of the floor joist, or any other code-required nailing.

3. While round holes are preferred, rectangular holes may be used providing the corners are not over-cut. Slightly rounding corners or pre-drilled corners with a 25 mm diameter bit is recommended.


SmartRim over an opening

Do not cut holes in SmartRim over an opening except for holes of 40 mm or less in size (see note 1).



SmartJoist/SmartRim near concentrated vertical load


4. When concentrated loads are present on the SmartJoist/SmartRim (loads not supported by any other vertical-load-carrying members such as squash blocks), holes should not be placed in the SmartJoist/SmartRim within a distance equal to the depth of the SmartJoist/SmartRim from the area of loading.



5. For multiple holes, the clear spacing between holes shall be at least two times the diameter of the larger hole, or twice the length of the longest rectangular hole. This minimum hole spacing does not apply to holes of 40 mm or less in diameter, which can be placed anywhere in the rim board (see note 1 for holes over opening) except that the clear distance to the adjacent hole shall be 75 mm minimum.

Multiple holes for SmartJoist/SmartRim

6. All holes shall be cut in a workman-like manner in accordance with the limitations listed above.




Rafter cuts of SmartJoists

SmartJoists can be “rafter cut” but only within the limitation shown below.


Rafter cuts are limited to:

- 1) 115 mm MINIMUM end height
- 2) MINIMUM Roof Slopes of 1 in 2 (approximately 26.5°), and
- 3) Must be blocked at the end to prevent rotation of the joist.

Joists without reinforcement are limited to design shear and end reactions up to 6.5 kN Ply reinforcement can be added to joists with rafter cuts to increase the shear and end reaction capacity of the joist. The detail below shows the proper installation of the reinforcement. With the reinforcement added, the end reaction and shear capacity increase to 12.7 kN Duration of load increases are permitted as per AS:1720.1.



Oblique connection details




NOTE:


It is recommended that the FL/FR joist hangers as shown on page 6 be used for members at 45° to the support. For members at angles other than 45°, the VS (variable skew) brackets or the LVSI bracket shown here may be used.

SmartJoist hole and duct charts


DON'T MAKE HOLES WITH HAMMER OTHER THAN PRE-PUNCHED KNOCKOUTS



DON'T HAMMER ON FLANGES AND DAMAGE JOINT



**DO NOT CUT OR NOTCH FLANGES
DO NOT OVER CUT HOLES IN WEB**



Note: The most accurate method to design the allowable web penetration size and distance from support for SmartJoists is to use the SmartFrame software. The table below will give conservative results in some instances. Also, advice on hole size and location may be obtained by contacting the Technical Support Helpline on 1300 668 690 or at techsupport@tilling.com.au.

LOAD ASSUMPTION (DL = 62 kg/m², FLL = 2 kPa, FPL = 1.8 kN)

Joist code	Joist span (mm)	Joist spacing (mm)	Circular/square holes								Rectangular holes				
			Hole diameter/Square hole width (mm)								Depth x Width (mm)				
			75	100	125	150	175	200	225	250	125x150	150x300	175x350	200x400	
Minimum distance from any support to the centre of the hole (mm)															
SJ20044	600-999	300 to 600	300	300	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	1000-1499		300	300	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	1500-1999		300	300	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	2000-2499		300	600	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	2500-2999		300	800	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	3000-3300		300	900	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
SJ24040	600-999	300 to 600	300	300	300	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	1000-1499		300	300	300	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	1500-1999		300	300	300	Span/2	ns	ns	ns	ns	ns	750	Span/2	ns	ns
	2000-2499		300	300	300	Span/2	ns	ns	ns	ns	ns	1000	Span/2	ns	ns
	2500-2999		300	300	500	Span/2	ns	ns	ns	ns	ns	Span/2	Span/2	ns	ns
	3000-3500		300	300	800	Span/2	ns	ns	ns	ns	ns	Span/2	Span/2	ns	ns
SJ24051	600-999	300 to 600	300	300	300	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	1000-1499		300	300	300	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	1500-1999		300	300	300	Span/2	ns	ns	ns	ns	ns	750	Span/2	ns	ns
	2000-2499		300	300	300	Span/2	ns	ns	ns	ns	ns	1000	Span/2	ns	ns
	2500-2999		300	300	500	Span/2	ns	ns	ns	ns	ns	Span/2	Span/2	ns	ns
	3000-3499		300	300	800	Span/2	ns	ns	ns	ns	ns	Span/2	Span/2	ns	ns
3500-3800	300	300	1000	Span/2	ns	ns	ns	ns	ns	Span/2	Span/2	ns	ns		
SJ24070	600-999	300 To 600	300	300	300	ns	ns	ns	ns	ns	ns	ns	ns	ns	ns
	1000-1499		300	300	300	ns	ns	ns	ns	ns	ns	300	ns	ns	ns
	1500-1999		300	300	300	Span/2	ns	ns	ns	ns	ns	600	Span/2	ns	ns
	2000-2499		300	300	300	Span/2	ns	ns	ns	ns	ns	900	Span/2	ns	ns
	2500-2999		300	300	500	Span/2	ns	ns	ns	ns	ns	1250	Span/2	ns	ns
	3000-3499		300	300	800	Span/2	ns	ns	ns	ns	ns	1500	Span/2	ns	ns
	3500-3999		300	300	1000	Span/2	ns	ns	ns	ns	ns	Span/2	Span/2	ns	ns
	4000-4100		300	450	1100	Span/2	ns	ns	ns	ns	ns	Span/2	Span/2	ns	ns

SmartJoist hole charts (Cont'd)

LOAD ASSUMPTION (DL = 62 kg/m ² , FLL = 2 kPa, FPL = 1.8 kN)														
Joist code	Joist span (mm)	Joist spacing (mm)	Circular/square holes								Rectangular holes			
			Hole diameter/square hole width (mm)								Depth x Width (mm)			
			75	100	125	150	175	200	225	250	125x150	150x300	175x350	200x400
			Minimum distance from any support to the centre of the hole (mm)											
SJ24090	600-999	300 to 600	300	300	300	ns	ns	ns	ns	ns	ns	ns	ns	ns
	1000-1499		300	300	300	ns	ns	ns	ns	ns	300	ns	ns	ns
	1500-1999		300	300	300	700	ns	ns	ns	ns	500	750	ns	ns
	2000-2499		300	300	300	1000	ns	ns	ns	ns	800	1000	ns	ns
	2500-2999		300	300	400	1150	ns	ns	ns	ns	1100	Span/2	ns	ns
	3000-3499		300	300	700	1400	ns	ns	ns	ns	1400	Span/2	ns	ns
	3500-3999		300	300	800	1550	ns	ns	ns	ns	1700	Span/2	ns	ns
	4000-4100		300	300	900	1600	ns	ns	ns	ns	1800	Span/2	ns	ns
SJ30040	600-999	300 to 600	300	300	300	300	300	300	ns	ns	300	300	ns	ns
	1000-1499		300	300	300	300	300	300	ns	ns	300	500	Span/2	ns
	1500-1999		300	300	300	300	300	500	ns	ns	300	Span/2	Span/2	Span/2
	2000-2499		300	300	300	300	300	700	ns	ns	500	Span/2	Span/2	Span/2
	2500-2999		300	300	300	300	400	1000	ns	ns	900	Span/2	Span/2	Span/2
	3000-3499		300	300	300	300	600	1200	ns	ns	1300	Span/2	Span/2	Span/2
	3500-3999		300	300	300	300	900	1450	ns	ns	1750	Span/2	Span/2	Span/2
	4000-4100		300	300	300	400	1000	1500	ns	ns	Span/2	Span/2	Span/2	ns
SJ30051	600-999	300 to 600	300	300	300	300	300	300	ns	ns	300	300	ns	ns
	1000-1499		300	300	300	300	300	300	ns	ns	300	500	Span/2	ns
	1500-1999		300	300	300	300	300	500	ns	ns	300	750	Span/2	Span/2
	2000-2499		300	300	300	300	300	700	ns	ns	400	Span/2	Span/2	Span/2
	2500-2999		300	300	300	300	400	1000	ns	ns	800	Span/2	Span/2	Span/2
	3000-3499		300	300	300	300	600	1200	ns	ns	1200	Span/2	Span/2	Span/2
	3500-3999		300	300	300	300	900	1450	ns	ns	1600	Span/2	Span/2	Span/2
	4000-4300		300	300	300	400	1000	1600	ns	ns	1800	Span/2	Span/2	ns
SJ30070	600-999	300 to 600	300	300	300	300	300	300	ns	ns	300	300	ns	ns
	1000-1499		300	300	300	300	300	300	ns	ns	300	500	Span/2	ns
	1500-1999		300	300	300	300	300	500	ns	ns	300	750	Span/2	Span/2
	2000-2499		300	300	300	300	300	700	ns	ns	400	1000	Span/2	Span/2
	2500-2999		300	300	300	300	400	950	ns	ns	700	1250	Span/2	Span/2
	3000-3499		300	300	300	300	600	1200	ns	ns	1000	Span/2	Span/2	Span/2
	3500-3999		300	300	300	300	900	1450	ns	ns	1400	Span/2	Span/2	Span/2
	4000-4499		300	300	300	500	1100	1700	ns	ns	1800	Span/2	Span/2	Span/2
4500-4600	300	300	300	700	1200	1800	ns	ns	1900	Span/2	Span/2	Span/2		
SJ30090	600-999	300 to 600	300	300	300	300	300	300	ns	ns	300	300	ns	ns
	1000-1499		300	300	300	300	300	300	ns	ns	300	400	Span/2	ns
	1500-1999		300	300	300	300	300	300	ns	ns	300	750	Span/2	Span/2
	2000-2499		300	300	300	300	300	600	ns	ns	300	950	Span/2	Span/2
	2500-2999		300	300	300	300	300	800	ns	ns	500	1200	Span/2	Span/2
	3000-3499		300	300	300	300	400	1100	ns	ns	800	1500	Span/2	Span/2
	3500-3999		300	300	300	300	700	1300	ns	ns	1200	1750	Span/2	Span/2
	4000-4499		300	300	300	300	950	1600	ns	ns	1600	Span/2	Span/2	Span/2
4500-4900	300	300	300	500	1100	1800	ns	ns	1800	Span/2	Span/2	Span/2		

SmartJoist hole charts (Cont'd)

LOAD ASSUMPTION (DL = 62 kg/m ² , FLL = 2 kPa, FPL = 1.8 kN)																
Joist code	Joist span (mm)	Joist spacing (mm)	Circular/square holes								Rectangular holes					
			Hole diameter/square hole width (mm)								Depth x Width (mm)					
			75	100	125	150	175	200	225	250	125x150	150x300	175x350	200x400		
			Minimum distance from any support to the centre of the hole (mm)													
SJ36058	600-999	300 to 600	300	300	300	300	300	300	300	300	300	300	300	ns	ns	
	1000-1499		300	300	300	300	300	300	300	300	300	300	300	300	400	ns
	1500-1999		300	300	300	300	300	300	300	300	400	300	300	700	Span/2	
	2000-2499		300	300	300	300	300	300	300	300	700	300	550	900	Span/2	
	2500-2999		300	300	300	300	300	300	300	400	900	300	850	1200	Span/2	
	3000-3499		300	300	300	300	300	300	300	650	1200	300	1200	1500	Span/2	
	3500-3999		300	300	300	300	300	400	900	1400	300	1500	1750	Span/2		
	4000-4499		300	300	300	300	300	600	1100	1700	300	1800	Span/2	Span/2		
	4500-5000		300	300	300	300	300	800	1400	1900	300	2200	Span/2	Span/2		
SJ36090	600-999	300 to 600	300	300	300	300	300	300	300	300	300	300	300	ns	ns	
	1000-1499		300	300	300	300	300	300	300	300	300	300	300	300	ns	
	1500-1999		300	300	300	300	300	300	300	300	300	300	300	450	700	
	2000-2499		300	300	300	300	300	300	300	300	400	300	300	750	1000	
	2500-2999		300	300	300	300	300	300	300	300	650	300	450	1000	1250	
	3000-3499		300	300	300	300	300	300	300	300	900	300	800	1300	1500	
	3500-3999		300	300	300	300	300	300	500	1150	300	1100	1600	Span/2		
	4000-4499		300	300	300	300	300	300	750	1400	300	1450	1900	Span/2		
	4500-4999		300	300	300	300	300	400	1000	1650	300	1800	2200	Span/2		
5000-5400	300	300	300	300	300	600	1200	1800	300	2100	2500	Span/2				
SJ40090	600-999	300 to 600	300	300	300	300	300	300	300	300	300	300	300	ns	ns	
	1000-1499		300	300	300	300	300	300	300	300	300	300	300	300	ns	
	1500-1999		300	300	300	300	300	300	300	300	300	300	300	300	400	
	2000-2499		300	300	300	300	300	300	300	300	300	300	300	300	600	
	2500-2999		300	300	300	300	300	300	300	300	300	300	300	300	900	
	3000-3499		300	300	300	300	300	300	300	300	300	300	300	600	1200	
	3500-3999		300	300	300	300	300	300	300	300	400	300	300	1000	1500	
	4000-4499		300	300	300	300	300	300	300	300	600	300	300	1300	1800	
	4500-4999		300	300	300	300	300	300	300	300	800	300	500	1700	2100	
	5000-5499		300	300	300	300	300	300	400	900	300	1000	2000	2500		
	5500-5700		300	300	300	300	300	300	500	1100	300	1200	2200	2750		



Notes:

1. The hole chart is generated on a maximum floor dead load of 62 kg/m² with no wall or roof loads. It therefore does not apply for joists supporting either parallel or perpendicular load bearing walls. These scenarios can be analysed by using the appropriate model within the SmartFrame software. Help can be obtained by contacting the SmartFrame Customer Helpline on 1300 668 690 or at techsupport@tilling.com.au
2. Hole locations are suitable for joist spacing's up to 600 mm centres. Holes may be permitted closer to supports for some members when spacing's of 450 or 300 mm are used
3. The clear distance between holes must equal or exceed twice the diameter of the largest hole, or twice the longest side of a rectangular hole and no more than 3 holes in excess of 75 mm are allowed in any span
4. Do not cut or damage flanges under any circumstances
5. Except as noted in 1 and 2 above, a 40 mm hole at a minimum of 450 mm centres is allowed to be drilled anywhere in the web EXCEPT in cantilevered spans
6. If possible, holes in web should be positioned mid height, minimum edge clearance from any flange is 6 mm
7. A group of round holes at approximately the same location shall be permitted if they meet the requirements for a single round hole circumscribed around them.

Example construction details for load bearing cantilevers




Note:

Option 1 with cantilever reinforced with an extra SmartJoist is equivalent to option 2 with 2 sheets of plywood



NOTE:
Block together full length with filler blocks as per detail F15 of the SmartJoist Design Guide


NOTE:
15mm F11 structural ply is required on one or both sides of the joist (See Tables). Depth shall match the full height of the SmartJoist. Nail with 3.15 x 65 nails at 100mm ctrs in a staggered pattern.



SmartJoists supporting parallel load bearing walls


Fitted floors

Double SmartJoists required for fixing of floor and ceiling, and when required by table below
AND
for SmartJoists with 40 mm wide flanges




Platform floors

Single SmartJoist with flange > 50 mm may be used, but requires alternative fixing for ceiling.
NOT suitable for SmartJoists with 40 mm wide flanges e.g. SJ24040




Joists continuously supported by lower walls



Fix 90x45mm F5 compression block to SmartJoist where load exceeds 6.5 kN*


Concentrated point loads (eg, girder trusses, TG's all beams & jamb studs)



F30a

Single SmartJoists with flange width < plate width


Concentrated point loads (eg, girder trusses, TG's all beams & jamb studs)



F30b

Single SmartJoists with flange width >= plate width

Concentrated point loads (eg, girder trusses, TG's all beams & jamb studs)




F30c

Fix 90x45mm F5 compression block to single rim board where load exceeds 26.0 kN*

Single SmartRim

Joist non-continuously supported by lower wall



Single (and double) SmartJoists are adequate to transfer uniformly distributed compression loads up to 29 kN/m per joist from loadbearing walls to a continuous rigid support below.


Detail F5 and F8 are used to transfer concentrated loads where walls are perpendicular to the joists. Details F30a, F30b and F30c above must be used to transfer concentrated loads through parallel SmartJoists where the instantaneous reaction exceeds 6.5

kN and exceeds 26.0 kN for single SmartRim (reaction needs to be factored for load duration)


The table in the SmartJoist Design Guide gives allowable spans for single and double joists NOT continuously supported by a parallel wall. Care must always be taken to adequately support the web of the joists from concentrated point loads from above by adopting details F13.

Typical SmartJoist Roof details



Warning:
Do not allow workers or loads on roof until ALL blocking, hanger, bracing and fastening is completed.
See Safety warning




Web stiffeners required each side of SmartJoist. Bevel cut stiffeners to match roof of slope. See Detail F12b.




Web stiffeners required each side of SmartJoist. Bevel cut stiffeners to match roof of slope. See Detail F13.




25x1.0mm G.I. strap with 7/35 x 3.15mm nails each end



25x1.0mm G.I. strap with 7/35 x 3.15mm nails each end












Joist shall be designed using design properties when "L" exceeds joist spacing.




Note: Tiedown details to be designed to AS 1684.2 for the respective wind loads with the SmartFrame software


Typical SmartJoist Roof details (cont'd)





Rafter tie-down and blocking





Typical SmartJoist Roof details (cont'd)





Lateral restraint at supports




Trimming of roof openings



Lateral restraint - SmartJoist blocking fixing



Lateral restraint for rafters - Use of ceiling options to provide lateral support




Outrigger rafters - LVL

SmartJoist rafter tie-down

SmartJoist rafters need to be tied down in wind uplift situations in a similar manner to solid timber as shown in section 9 of AS 1684. The examples shown in this section are equally applicable to SmartJoists except that web stiffeners as per detail F13 and R1 must be installed to the SmartJoists where either skewed nails or framing anchors are chosen as the tie down method before the uplift capacities in the tables in section 9 of AS 1684 can be adopted.

All tie down types that involve a strap over the top of the SmartJoist rafters, or involving the bolting down of a member above the rafter running in the perpendicular direction, require no modification to the SmartJoist and the uplift capacities in the tables in section 9 of AS 1684 may be used.



Typical SmartJoist rafter box gutter rebate details

Box gutter rebates

Rebates for box gutters are permissible within a roof constructed with SmartJoist rafters to the MAXIMUM rebate limits as shown below.

- Fig BG1 with 2 pieces of 90 x 45 nailed to the web reduces shear capacity by 40%
- Fig BG2 with 2 pieces of 17 mm F14 ply nailed to the web maintains full shear capacity

Given that the design shear values at the end of rafters with light weight roofs are usually very low compared to the allowable shear, in most instances fig BG1 is satisfactory to provide a box gutter rebate within the SmartJoist rafters, however the remaining shear capacity MUST be checked.

It is recommended that designers wishing to cut box gutter rebates in SmartJoist rafter contact the Technical Support Helpline on 1300 668 690 or at techsupport@tilling.com.au for further advice on this issue.

